

Replacement Fabric Print

Installation

Changing the fabric print on the frame or lightbox:

1. Pull on the label of the fabric print that you want to remove from the frame or lightbox for it to easily come off.



2. Take one corner of the replacement fabric print and insert the silicone edge trim into the slot of the frame or lightbox. Repeat the same thing with each corner of the replacement fabric print.

3. Push in the central part of the silicone edge trim on each of the four sides.



4. Finish by smoothing the perimeter of the fabric print so that the silicone is pressed evenly all over.